



### GUIDE FOR ACCESSORIES

- 1- Sand lightly with a 120 grit sandpaper and remove the residue with a clean rag.
- 2- **Step A** : Shake well the coloured base can and use a roller to apply a thick coat.
- 3- Let dry 24 hours.
- 4- Sand lightly with a 120 grit sandpaper to create an aged look around board edges and remove the residue with a clean rag.
- 5- **Step B** : Shake well the coloured oil can (Primol) and pour a small quantity on a clean rag. Apply thin coats using circular motions.
- 6- Let dry at least for 24 hours.
- 7- **Step C** : Shake well the finishing oil can (Greenol) and pour a small quantity on a clean rag. Apply thin coats using circular motions.
- 8- Let dry 24 hours.



NAIVE