



## GUIDE FOR ACCESSORIES

- 1- Thoroughly sand the surface with a 120 or 150 grit sandpaper and remove the residue with a clean rag.
- 2- **Step A** : Shake well the coloured base. Apply a thin coat with a brush and let dry four hours.
- 3- Manually sand the black base coat in every direction with a 120 or 150 grit sandpaper. To imitate the flooring effect, sand randomly certain spots until the black colour becomes greyish.
- 4- **Step B** : Shake well the coloured oil. Apply a coat with a brush and remove the excess stain with a clean rag.
- 5- Let dry one hour.
- 6- The amount of sanding will result in the final finish. If it is different than your floor, sand again and restart to step one.
- 7- Apply a clear varnish of the desired gloss.



MONTANA