



GUIDE FOR ACCESSORIES

- 1- Thoroughly sand the surface with a 120 or 150 grit sandpaper and remove the residue with a clean rag.
- 2- **Step A** : Shake well the stain. Apply a thin coat with a brush and remove the excess stain with a clean rag.
- 3- Let dry six hours.
- 4- **Step B** : Shake well the coloured sealer. Apply a coat with a brush.
- 5- Let dry two to four hours.
- 6- **Step C** : Shake well the pearly sealer. Apply a coat with a brush.
- 7- Let dry two to four hours.
- 8- Carefully sand with a 400 grit sandpaper and remove the residue with a clean rag.
- 9- Apply a clear varnish of the desired gloss.



AKOYA