

MAKING MINOR REPAIRS TO A BOARD

PREPARATION

- Clean the damaged area with Model cleaner.

WAX STICK (To be used only if necessary)

Use only if the damaged section is deep and requires filling.

- Rub the stick in the defect.
- Remove surplus wax using a stiff piece of cardboard or a spatula.

STAIN

- Shake the container.
- Apply to the surface in small amounts.
- Reapply if darker shade is desired.
- Wipe away excess stain with a clean cloth.
- Allow to dry for 15 minutes.

Finish

- Apply a thin coat and allow to dry for 30 minutes.
- Apply a second coat and allow to dry for 4 hours.
- If a third coat is necessary, sand lightly with the Scotch Brite supplied with the kit before applying varnish. Then allow to dry overnight.

